



STEWART



OWNER'S MANUAL





IMPORTANT INFORMATION

This machine is designed solely for the transportation of golf equipment on a golf course.

Warnings and important safety instructions appearing in this manual are not meant to cover all possible conditions and situations that may occur. Common sense, caution and care must be exercised when operating or cleaning this equipment.

Always contact Stewart Golf or your local distributor/dealer about problems or conditions that you do not understand.

INTELLECTUAL PROPERTY

The design and technology within the Stewart Golf V10 Remote, as well as the Stewart Golf brand is protected by numerous trademarks, design registrations and patents. For a full register of Stewart Golf intellectual property please visit stewartgolf.com/IP.

GOLF BAG TYPE & WEIGHT

The V10 Remote has been optimised for use with a cart or tour style bag weighing **14kg (31lbs)**. Weigh your golf bag and ensure it is between 13kg (28lbs) and 15kg (33lbs).

Using a light and often 'top heavy' stand bag reduces the load on the front wheels, which means the steering may react faster than intended, and the machine will spend more time on the stabiliser than is desirable.

Using a golf bag heavier than advised increases the load on the front wheels, slowing steering speeds. Additionally a heavy bag will increase the strain and wear on the structure of the V10 Remote, reduce your battery life and increase the risk of overloading the electronics and motors.

IMPORTANT NOTICES:

This red box is used from time to time in this manual to indicate a potentially hazardous situation which, if not avoided, could result in damage to the product, serious injury or death.

CERTIFICATION:

This machine has been tested and conforms to:

EN 61000-6-3:2007+A1:2011
FCC Part 15 Class B
EN 61000-6-1:2019

For further certificates and declaration of conformity please visit stewartgolf.com/technical.

CONTENTS

2	Important Information
3	Welcome
4	V10 Remote Anatomy
6	Setting Up
7	Putting Away
8	Battery Charging
10	Handset Guide
11	Handset Charging & Care
12	Manual Operation
14	Remote Control
16	Other Features
17	FAQ
18	Warranty Information
19	Trouble Shooting Guide

WELCOME

Congratulations on buying a Stewart Golf V10 Remote!

First things first: resist the temptation to take your V10 Remote straight out for a round immediately – first read this manual **fully** as it contains important safety information, but more importantly tips and advice on how to get the very best experience when using the machine.

BEFORE YOU GET TOO EXCITED:

The first thing that you should do is give both the main battery and handset a full charge, instructions are found on pages 8 and 11.

Next, practice with it. Find an area of open grass with your normal golf bag on the machine, with all your clubs and everything else in it: we recommend a weight of 14kg or 31lbs. Using it on grass is important: speed and steering are both affected by the surface the V10 Remote is on, and it's obviously designed to be used on grass.

Remember to practice with both modes of operation: manual and remote. Even though the word 'remote' is used in the name, manual steering (holding the handle) is just as useful in the right circumstances.

You should steer the machine manually from the handle when on paths or in a car park (for example), or by using remote control in open areas, or when directing the machine around tees and greens. Please see pages 12-15 for more on this.

There are lots of videos available at: www.stewartgolf.com and on our YouTube channel (youtube.com/stewartgolfuk): they'll help you get the most from your V10 Remote .

V10 REMOTE ANATOMY

The V10 Remote is made from a unique construction of bonded composites and injection mouldings, probably very different from any other trolley you may have owned in the past. Here you can familiarise yourself with its basic features and parts.

- | | |
|---------------------------|----------------------------------|
| 1. Handle | 11. Handset Cradle |
| 2. Scorecard Holder | 12. Accessory Point |
| 3. Golf Ball & Tee Holder | 13. Bluetooth Light |
| 4. Top Bungee | 14. On/Off Button |
| 5. Bag Cushion | 15. Main Support Release Buttons |
| 6. Main Support | 16. Rear Stabiliser |
| 7. Front Cover | 17. Rear Cover |
| 8. Bottom Bungee | 18. Rear Wheels |
| 9. Front Lifting Point | 19. Front Wheels |
| 10. Front Cover "S" Clips | 20. Handle Release Clip |





UNDER THE COVER

Under the front cover you will find the main battery in a protective neoprene case, and the small black electronics system.



SETTING UP

1. When removing the V10 Remote from the car, only lift from the two lifting points. These are the stabiliser and under the front of the chassis (parts 9 and 16). **Lifting from other parts of the trolley cover could cause unintended damage that will not be covered under warranty.**
2. To unfold, simply grip the handle and pull it towards you. The top & bottom clips will snap into place automatically.
3. To remove the front cover, hold the two 'S' clips (part 10), apply slight outward pressure and lift.
4. Insert the battery into the tray and secure with the strap. Connect the battery to the electronics box.
5. Replace the front cover by aligning the two lugs on the straight edge with the corresponding gaps in the rear cover, and pivot in to place. Ensure the front of the cover is **behind** the small bump near the lower bag stay, apply downward pressure to the 'S' clips until the cover is secured.
6. Turn the on/off switch to 'ON' (I) and wait for the blue light to flash. Press the Bluetooth on/off button on the handset for 1 second to switch the handset on. When both blue lights are constantly illuminated, the Bluetooth connection is established.



FITTING YOUR GOLF BAG

1. Stand the base of your golf bag on the front chassis.
2. Lean the golf bag back until it rests on the silicone bag cushion.
3. Pull the upper bungee around the golf bag evenly and fix.
4. Pull the lower bungee over the bottom of the bag using the handle.

Note: The V10 Remote has been optimised for use with a cart or tour style bag weighing 14kg (31lbs). Please refer to page 1 for more information.



PUTTING AWAY

Prior to folding, clear any debris from the trolley using compressed air or a soft brush or cloth (**never** use water). Pay particular attention to the base of the main support arms for small stones or grit. See the FAQ for a cleaning guide.

1. Remove one side of the top bungee and lift your bag up & away from the machine. The bottom bungee will release automatically.
2. Remove the front cover, disconnect and remove the battery and replace the front cover.
3. Release both bottom clips simultaneously by pressing the clips with your thumbs. Slowly lower the main support until the top bag support comes to rest on the chassis.
4. Whilst supporting the handle, release the top clip and lower the handle until it comes to rest on the rear cover. Do not 'drop' the handle or main support.
5. Lift the V10 Remote in to your car using the lifting points specified.

WARNING:

Always ensure that your V10 Remote is turned **OFF** at the switch or disconnected completely when not in use. Leaving it **ON** or connected could drain the battery totally and risk irrecoverably damaging it.

Turning **OFF** or disconnecting the battery will ensure that the trolley is not accidentally activated in transit.

You may choose to remove the battery prior to folding to enable you to charge it.

In any case, it is good practice to always turn the switch to the **OFF (O)** position when not in use.

BATTERY CHARGING

The V10 Remote has two lithium batteries: one large battery that powers the trolley, and one small one that powers the handset. These pages cover the large trolley battery, the handset is discussed on page 10.

Always start a charging cycle by following these steps:

1. Connect the battery to the charger.
2. Connect the charger to the wall.
3. Switch the wall socket on.

The charger has an indicator light on it:

RED: Indicates the battery is charging.

GREEN: Indicates that the charge cycle has finished.

Note that the charger also shows green if connected to the wall but not the battery. The charge cycle time varies depending on how much power has been used: the average charge should take 3-4 hours, but can be up to 10 hours.

BEST PRACTICE

If the battery is being used regularly (once a week for example), it is OK to leave it connected to the charger, with the charger turned on. The Battery Management System (BMS) within the battery will prevent any damage. However it is good practice to disconnect the battery from the charger once the green light shows.

TECHNICAL INFORMATION

- Operating temperature: -10°C to 50°C (14°F to 122°F)
- Charging & storage temperature: 15°C to 25°C (59°F to 77°F)
- Battery Lifespan: >1000 charge cycles
- Nominal Voltage: 12.8V
- Charge current: 2-5A



LONG TERM STORAGE

If you are not going to use the V10 Remote for more than one month, the battery should be fully charged after its last game then disconnected from the charger and stored in a dry environment between 15°C and 25°C (59°F and 77°F).

Once a month you should put the battery through a full charge cycle. Before using it again, the battery should be given a full charge cycle.

Batteries are a complex technology and a number of variables contribute to battery performance and thus the performance of your V10 Remote.

All rechargeable batteries are consumables and have a limited lifespan: eventually their capacity and performance decline so that they need to be replaced. As batteries age, it can contribute to changes in their performance.

BATTERY LIFE & BATTERY LIFESPAN

"Battery life" is the amount of time your machine will run for before the battery needs to be recharged. *"Battery lifespan"* is the amount of time a battery lasts until it needs to be replaced. The mix of things you do with your V10 Remote affects battery life and lifespan but no matter how you use it, there are ways to help.

A battery's lifespan is related to its "chemical age", which is more than just the passage of time. It includes different factors, such as the number of charge cycles and how it was cared for.

To help maximise battery performance and help extend battery lifespan, avoid charging or leaving the battery in very hot environments (including direct sun exposure) for extended periods of time.

Please read and follow the advice in this manual.

CARING FOR YOUR BATTERY

- **DO** follow these instructions exactly.
- **DO** only use the charger supplied to charge the battery.
- **DO** charge the battery immediately after each use, certainly within 48 hours.
- **DO** ensure the battery is fully charged before each round to ensure you have sufficient power to complete your round.
- **DO** charge in a well ventilated area.
- **DO** store & charge the battery in a dry environment between 15°C and 25°C (59°F and 77°F).
- **DO** fully disconnect and unplug the charger from the mains and battery between charges.
- **DO NOT** drop, throw, puncture or crush the battery.
- **DO NOT** immerse in water or any liquid.
- **DO NOT** use water or a hose to clean the battery.
- **DO NOT** clean with any abrasives or solvents; a damp cloth is fine.
- **DO NOT** leave the battery in a discharged state.
- **DO NOT** open or disassemble the battery or charger. This is dangerous and will void the warranty.
- **DO NOT** cover during use or charging.
- **DO NOT** expose the battery extreme temperatures (**never** store in a car in winter or summer.)
- **DO NOT** solder or connect anything to the terminals other than as guided in this manual.

HANDSET GUIDE

Your V10 Remote is supplied with a rechargeable Bluetooth handset, which is already paired with your machine. It has a number of innovative features which you can learn about below.

1. Forward/speed up.
2. Indicator light.
3. Left & right turn.
4. STOP. Use as primary stopping function.
5. Slow down/reverse.
6. Glide stop.
7. Cruise Control speeds (see P16).
8. Bluetooth ON/OFF. Press & hold for one second to turn on. When turning off, a red light shows momentarily.

In normal use, the indicator light will be blue:

LIGHT OFF: Handset is switched off.

BLUE LIGHT FLASHING: Handset is on, but not connected to the machine.

BLUE LIGHT ON: Handset is on and connection has been established.

RED FLASHING LIGHT: Battery low.

YOUR HANDSET AND TROLLEY ARE ALREADY PAIRED.

If you need to re-pair for any reason, please scan below for a video guide.



or follow this link:
<https://bit.ly/3KUwRnJ>



HANDSET CHARGING GUIDE

The handsets' lithium battery can last for up to two rounds of golf, however, it should be charged after every round to ensure sufficient power.

Always charge the handset indoors and at room temperature, observing the same DO and DO NOT advice on page 9. The charging process can take up to six hours.

1. Ensure the handset is switched off and the indicator light is off.
2. Remove the protective silicone skin.
3. Expose the charging port on the side of the handset by pulling out the black plug.
4. Connect the supplied USB power cable to any 5V/1A USB power outlet.
5. Connect the supplied USB power cable to the handset & turn on power at the wall (if applicable).
6. The indicator light on the handset will show **RED** while charging and turn **GREEN** when fully charged.
7. Once the indicator light is **GREEN**, disconnect the power cable from the handset.
8. Return the black plug to the charging port on the side of the handset, then refit the protective silicone skin.

WARNING

The handset should **only** be charged with the supplied USB power cable provided. Using any other cable or power source can damage internal components: this **will not** be covered under warranty.

HANDSET CARE

Using the handset skin and charging port plug means that the handset will be shower proof (it is not waterproof). Water and electronics are natural enemies and you must take care to make sure no water ever gets inside the handset.

- Never allow the handset to be immersed in water and don't wash it.
- If you want to wash the silicone skin, remove it from the handset before washing it, then dry it thoroughly before replacing it.
- If you use the handset in the rain or other wet conditions, remove the silicone skin as soon as you have finished playing and wipe both handset and silicone skin dry to remove any moisture that may have found its way down the edges of the silicone skin. Allow both to dry fully before refitting the silicone skin.
- Don't store the handset anywhere that water or moisture might get into it.
- Refer to the **DO** and **DO NOT** guide on page 9 for further advice on how to care for the handset and lithium battery contained within.

LONG TERM STORAGE

If you are not going to use your V10 Remote for more than one month, the handset should be put through a charge cycle at least once every month.

This will avoid the handset battery being completely discharged. Prior to using the handset again it should be fully charged.

MODES OF OPERATION

Your V10 Remote has **TWO** modes of operation: manual and remote control.

Both make use of the remote control handset, but manual requires you as the user to hold the handle to control the direction of the trolley, as shown opposite. It is your responsibility to choose the correct steering mode for each situation, please read more for tips on how to make these decisions.

The V10 Remote features Active Terrain Control (ATC) which is active at all times. This technology will ensure the machine maintains speed when travelling both up and down slopes. These processes are automatic and don't require user input.

1. MANUAL OPERATION

Good for: Tight spaces, car parks, bridges, paths.

Before you do anything, make sure you know where the STOP button is and always use this as the main command to bring the machine to a halt.

If you wish to bring the machine to a more gentle halt, use the Glide Stop button.

When in a car park, crossing a road or negotiating a tight path, you should steer manually from the handle. You can control the speed of the machine using the speed up & slow down buttons, or program the cruise control speeds to your walking pace (see page 18).

BEST PRACTICE:

When in tight areas you should physically keep control of the V10 Remote by steering from the handle.

The handle allows you to steer with either hand. Either clip the handset to the handle, or hold the handset with your spare hand.

WARNING

Ensure you practice in an open area away from other people or objects.

This will allow you to familiarise yourself with the remote functions without risk of damage or injury. Be aware of your surroundings. Ensure that you know the whereabouts of other players, carts, trees, lakes, bunkers, streams etc.



2. REMOTE CONTROL

Good for: On fairways, around the greens or when you are in the rough.

Not for: Car parks, bridges, paths.

To start the machine moving forwards, press the forward button. Once the machine is in motion, continually pressing the 'forward' or 'reverse' buttons will either speed up or slow down the machine. You can also use the cruise control buttons to start the machine.

To reverse the machine, press 'STOP' and then select the 'reverse' button. When reversing, the speed is fixed and cannot be increased or decreased.

To steer the machine, press and release either the left or right buttons. When in motion this will change the direction slightly and continue moving. A prolonged press will tighten the turn. If you press either button with the V10 Remote stationary, the machine will turn on the spot.

The advanced Bluetooth connectivity can give a range of more than 100 yards; but this is excessive for normal use. As a result, we have added a further safety protocol to ensure your trolley always remains fully under your control.

Once the signal strength drops below a certain level, indicating that the trolley is approximately 25 yards from the handset, if no button has been pressed on the handset for more than three seconds, the trolley will stop immediately.

The trolley and handset will remain paired and pressing any button will then give you back full control, but buttons will need to be pressed every three seconds. Until the signal strength indicates the trolley is back within 25 yards of the handset.

The three-second protocol will remain in place whenever the trolley is more than 25 yards away from the handset, but closer than its maximum Bluetooth pairing range. Should the trolley ever exceed its Bluetooth pairing range, it will disconnect from the handset and the trolley will stop as a safety measure. Walking the handset back into the pairing range will initiate re-pairing.

BEST PRACTICE:

- The remote has a nominal 100 yard range. However it is recommended that you keep the machine within 25 yards so that you can see obstacles in its way.
- Hold the handset in your hand and position the machine approximately 10-15 yards in front of you and on the line of your ball. Make small adjustments to direction and speed as you see fit. Do not place the handset in your pocket.
- When you get to your ball, park the machine to the right of your ball (or to the left if you are left handed). Place the handset on the cradle when taking a shot.
- If you are going to walk any distance away from the machine (such as on the green), keep your handset with you so you can drive it to your next position rather than walking back to it.



IMPORTANT INFORMATION

The V10 Remote can travel at speeds of up to 6mph but performing delicate manoeuvres, such as negotiating bridges or steering between obstacles, should not be performed at top speed. The machine will perform best when being driven at walking speed and this is what is strongly recommended. Any damage caused by collisions of any kind will NOT be covered by warranty.

OTHER FEATURES

HANDLE FEATURES

As standard the V10 Remote has:

- Built in scorecard and pencil holder.
- Handset cradle.
- Golf ball and tee holder.

CRUISE CONTROL SPEEDS

Your V10 Remote has three Cruise Control speeds, on buttons 1, 2 and 3. You can program these for your own walking speeds as follows:

1. Use the speed up and slow down buttons to find your desired walking speed.
2. Press and hold either button 1, 2 or 3 for three seconds. The machine will stop to show that the instruction has been received. Now release the button and the machine will restart. Your new speed is now stored.
3. To activate the new speed press button 1, 2 or 3 and release the button as normal.

TRIM ADJUSTMENT

If your motors become unbalanced for any reason, your V10 Remote may develop a bias. If this happens, you can adjust the trim as follows:

1. Ensure that your machine is on a flat surface and that your golf bag is balanced (no heavy items in side pockets).
2. Hold down the lower left two buttons (Cruise Control buttons 1 and 3) for five seconds. The machine will start moving forwards.
3. Use the left and right buttons to fine tune the direction until the machine is travelling in a straight line. Alternatively press the forward button to restore the factory setting.
4. Press STOP to store the new setting.

QUICK-RELEASE REAR WHEELS

To remove a wheel:

1. Tilt the machine (holding the main support) so that one wheel is off the floor.
2. Hold the centre of the wheel and press the metallic with your thumb, and pull the wheel away.

FREEWHEEL

The V10 Remote has a free-wheel setting which allows you to complete your round even in the unlikely event of a fault. To engage this mode:

1. Tilt the machine so that one wheel is off the floor (hold the main support).
2. Press down on the metallic button in the wheel centre and slide the wheel 25mm (1") away from the motor, but still on the axle.
3. Rotate the wheel 45 degrees and push it towards the motor until it stops, engaging the wheel on the outer ring of the axle.
4. Release the button and the wheel should now be locked on to the shaft, but not engaged onto the drive dog. You may find it easier to pull the V10 Remote than push it when in free-wheel.

FAQ

How should I clean the V10 Remote?

After your round, clear grass, leaves and dust etc from the machine using a soft cloth/brush or compressed air. Clean your V10 Remote using standard furniture polish and a soft cloth.

NEVER use a hose or pressure washer to clean the V10 Remote: faults caused by water ingress will not be covered by the warranty. Water cannot enter the motors or electronics in normal use.

Is the V10 Remote OK to use in the rain?

Yes. The V10 Remote is designed for use in all conditions appropriate for golf. The design of the V10 Remote protects the major components from rain, so water ingress cannot occur during normal use. You should avoid any situation where moisture or water could reach the electronics or motors. Some examples of this are:

- Driving through puddles or standing water.
- Submerging the machine in a river or lake.

Faults caused by water ingress will not be covered under the warranty.

How do I get the V10 Remote up a step or kerb?

Firstly exert downward pressure on the handle to lift the front wheels onto the higher level. If the natural traction of the rear wheels do not carry the rear of the machine onto the higher level, lift from the top of the main support.

How many holes will the battery last for?

We expect any genuine Stewart Golf battery to last 18 holes (or 36 with the extended capacity battery) on a 'normal' course, with a 'normal' weight bag and in 'normal' conditions.

However... a hole of golf can be anywhere between 100 and 600 yards long, so is not a reliable unit of measurement. Terrain, ground condition, bag weight and a number of other factors can make a difference. How you play will also affect power consumption; you'll cover less ground shooting 65 than you will shooting 120.

Can I improve the battery life?

Yes, there are a number of things you can do:

- Don't overload your golf bag.
- Steering is a big source of power consumption, so try to drive straight and on the short grass of the fairway to conserve energy.
- Accelerate slowly, in the same way you would in a car if you were trying to be efficient.

Can I use the V10 Remote without the handset?

No. The V10 Remote can only be operated via the handset (unless the wheels are in freewheel).

Can the V10 Remote cope on hills?

Yes. The V10 Remote chassis has been designed with stability in mind. The machine may tip onto the rear stabiliser, but if this happens don't worry - that's what it's there for!

Bag weight and weight distribution makes a big difference here, a light and/or top heavy bag will not put enough weight on the front wheels and therefore it may tip easily. You will find out which hills work with your particular setup through experience.

When going down hill using remote control, the V10 Remote may speed up under gravity.

Hold the handle if on a path or allow the machine to travel safely away from you, then use the red 'STOP' button to apply the brake. Always park at 90 degrees to a slope.

WARRANTY INFORMATION

Your Stewart Golf V10 Remote is guaranteed to be free from defects in materials or workmanship for a standard period of two (2) years from delivery.

If you think there may be a problem with your V10 Remote, the first thing to check is the troubleshooting guide opposite. If this does not solve your issue, please contact us or your local distributor for further advice.

Conditions of warranty:

If notice is received of any breach of this warranty during the relevant period, then we shall at our own expense and within reasonable time, repair, or at our option, replace the goods or such parts as are defective or otherwise remedy such defect. If your address is in the UK we will arrange and pay for collection.

If you are outside the UK, please contact your place of purchase or your local distributor or dealer.

Stewart Golf will authorise the repair, or at our option, replacement of any part found to be defective due to faulty workmanship or materials. We reserve the right to inspect these parts. We will not bear any costs incurred (including carriage) due to an item being returned with a suspected fault, and after inspection no fault can be found, or it is found that the customer has not fully understood all of the functions of the V10 Remote or the part in question.

Exclusions to the warranty include, but are not limited to: damage during return shipment if not packed in a Stewart Golf designated box or according to Stewart Golf instructions; wear & tear; results of neglect, misuse or accidents; damage howsoever caused; or utilisation for any purpose other than carrying a golf bag on a golf course. V10 Remote units, which have been fitted with non-genuine Stewart Golf parts, or have been modified from the manufacturers specifications, are excluded. Stewart Golf products used for commercial or rental purposes are excluded. The warranty is not transferable to a third party.

Both the handset battery and trolley battery is covered by a two (2) year warranty against faulty workmanship and materials. Loss of battery performance owing to external damage (howsoever caused), misuse and/or abuse, incorrect charging or other failures not attributable to a manufacturing defect are specifically excluded from this warranty. The handset and trolley batteries must be charged only with the equipment supplied by Stewart Golf, and the instructions must be followed exactly.

**Register your warranty:
stewartgolf.com/warranty**

TROUBLESHOOTING GUIDE FOR VERTX

SYMPTOMS

POSSIBLE ISSUE

POSSIBLE SOLUTION

The V10 Remote is not responding when I press a handset button.

1. Rear wheels may be in free-wheel.
2. On/Off switch on the trolley is off.
3. Handset battery is flat.
4. SmartPower battery is flat.
5. Out of range.
6. Handset not paired.

1. Follow the free-wheel guide on P16.
2. Turn the switch on the trolley to on (I)
3. Charge the handset.
4. Check the SmartPower status on the app.
5. Move closer to the machine.
6. Follow the pairing guide on P10 or below.

It is difficult to push the V10 Remote.

Free-wheel mode not engaged.

Use the quick release system to put the wheels in to the 'free-wheel' position.

The V10 Remote moves in circles when pressing the forward button.

One wheel in free-wheel, one in drive.

Ensure both wheels are fully engaged with the drive dogs (therefore npt in freewheel).

The V10 Remote does not travel in a straight line.

1. Bag not balanced.
2. Trim needs to be adjusted.

1. Ensure your bag is evenly weighted from side-to-side.
2. Follow the guide on P16.

The handset won't turn on.

Battery not charged.

Charge handset using USB power cable provided.

No power light on trolley.

1. No power from battery.
2. No power connection.
3. Switch / LED not connected.
4. Trolley not turning on.

1. Ensure main battery is charged.
2. Ensure a connection can be made between battery and trolley. Check terminals are clean and clear.
3. Check connections at either end.
4. Contact Stewart Golf for support.

The handset won't connect to my trolley

The handset may have become 'un-paired' from the trolley.

1. Turn ON the trolley
2. Remove the battery and wait until LED goes off
3. Using the handset press and hold the FORWARD button and then press the ON button - hold for a couple of seconds until the handset flashes red/yellow colour once flashing release both buttons, the handset is now in pairing mode
4. Re-insert the battery with trolley switch turned ON (Bluetooth pairing active for 15secs)
5. The handset will now pair to the trolley. Once the handset stops flashing, the LED will be a solid blue colour and pairing is complete.
6. The trolley and handset Bluetooth connection is now paired and the trolley can be used as normal.

IF YOUR ISSUE IS NOT RESOLVED AFTER FOLLOWING THIS GUIDE, PLEASE
CONTACT STEWART GOLF OR YOUR LOCAL REPRESENTATIVE.

A wide-angle photograph of a golf course under a clear blue sky. Two people, a man and a woman, are walking away from the camera on a green. The man is wearing a dark jacket and pants, and the woman is wearing a dark jacket and light-colored pants. They are walking towards two golf bags on push carts. The background features a line of trees with some autumn-colored foliage. The overall scene is bright and clear.

www.STEWARTGOLF.com

100389 VI