



StewartGolf
GREAT BRITAIN



R1-S PUSH

OWNER'S MANUAL

- Welcome

Congratulations on becoming the owner of a Stewart Golf R1-S Push. This product has been handbuilt in Great Britain to our usual exacting standards. Thank you for choosing a Stewart Golf product.

Warning and important safety instructions contained in this guide are not meant to cover all possible conditions and situations that may occur. Common sense, caution and care must be exercised when operation or cleaning this product.

Please read this short guide in full before you attempt to unpack, assemble or use the product:

- This trolley is designed solely for the transportation of golf equipment on a golf course.
- Always follow the folding and unfolding instructions carefully.
- Ensure that you keep clear of moving parts while unfolding, folding or adjusting the product.
- Always use the brake when parking the trolley to ensure it does not roll away.

- Stewart Golf customer care

If you have a question about your R1-S Push trolley, call the Stewart Golf Helpline on +44 (0) **0333 800 1818** or visit our website: **www.stewartgolf.com/support**.

Most questions can be solved over the phone by one of our Support staff. If your R1-S Push needs a service, call the Stewart Golf Helpline so we can discuss the available options.

If your machine is under warranty, and it is a covered repair, it will be repaired at no cost.


- Warranty

Stewart Golf warrants the R1-S Push to be free from manufacturing or material defects for a period of two (2) years (when registered) from the date of purchase. The warranty does not cover normal wear & tear, damage that occurs through abuse, accident, neglect or failure to follow the instructions or warnings contained in the user guide. Stewart Golf is the sole judge of any and all warranty claims. Proof of purchase is required.


Simply register your purchase at **stewartgolf.com/warranty**

- Unfolding


- 1 Remove the R1-S Push from the box and sit the trolley on the floor. Rock the R1-S Push backwards so the bag jaws are up in the air.




- 2 Loosen the handle knob



- 3 Rotate the handle so it is vertical. And tighten the handle knob.




- 4 Hold the handle in one hand and rotate the trolley forward so the frame lock is accessible, then open the frame lock.





5 Lift the handle, pulling upwards until the frame is fully open.

DO NOT STEP on the frame when unfolding. Doing so may damage the trolley and will invalidate your warranty.




6 Now close the frame lock




- Folding


- 1** Undo the frame lock



- 2** Push the handle up and over until the unit is folded as if you are trying to balance it




- 3** Close the handle lock to secure the frame.



- 4** Loosen the handle knob & lower the handle until it comes to rest. Now tighten the handle knob.



- 5** Done!



- Accessories

There are a number of accessories and attachments available for your brand new R1-S Push that have been designed to enhance your experience on the course.

From Umbrella Holders and Hedgehog Wheels, to Travel Bags and Rain Covers, you can find the perfect accessory for your trolley on our website.

Save 10% off all accessories with the discount code below.



Save 10% off accessories with code: R1OWNER10

DESIGN PROTECTION:

This product is protected by the following registrations:

GB Patent: GB2513930

European Design Registration: 2475913 & 2478545

US Patent Application: 14/465,980

For more information & other regions visit www.stewartgolf.com/IP.



StewartGolf
GREAT BRITAIN